

*Sunbeam*

# Cordless Filter

Cordless Automatic Kettle

INSTRUCTION BOOKLET.



KE2350

# Sunbeam's Safety Precautions.

---

## SAFETY PRECAUTIONS FOR YOUR KETTLE

- Boiling water will scald. Do not leave a boiling or hot kettle near or where children may touch it.
- Boiling water maybe ejected, if overfilled.
- Do not remove lid while water is boiling.
- Do not leave the power cord near the edge of a bench top where children may pull it.
- Do not move kettle while switched on.
- Always switch the power off and unplug the cord while the kettle is NOT in use.
- Do not operate the kettle and/or the power base on an incline surface.
- Do not operate the kettle without water.
- Do not operate the kettle unless the element is fully immersed in water or filled to the minimum level indicated.

## SAFETY PRECAUTIONS FOR ALL ELECTRICAL APPLIANCES

Sunbeam are very safety conscious when designing and manufacturing consumer products, but it is essential that the product user also exercise care when using an electrical appliance. Listed below are precautions which are essential for the safe use of an electrical appliance:

- **Read carefully and save all the instructions provided with an appliance.**
- Always switch off the power outlet before inserting or removing a plug. When removing the plug, do not pull on the cord.
- Always remove the plug when the appliance is not in use or before cleaning.
- Always use the appliance on a flat level surface.
- Do not use your appliance with an extension cord unless this cord has been checked and tested by a qualified electrical person.
- Always use your appliance from a power outlet delivering the rated voltage marked on the appliance.
- Close supervision is necessary when your appliance is being used near or by children or infirm persons.
- Never leave an appliance unattended while in use.
- Close supervision is necessary to ensure that children do not play with appliances.
- Do not use an appliance for any purpose other than its intended use.
- Do not allow water or liquids to come into contact with any switches or controls.
- Do not place an appliance on or near a hot gas flame, electric element or in a heated oven. Do not place and operate on top of any other appliance.
- Do not leave the power cord of an appliance near the edge of a table or bench top or touch any hot surface.
- Do not immerse appliance in water unless recommended.
- For safety reasons and to avoid maintenance by unskilled persons, some appliances are 'sealed' using tamperproof means. Such appliances should always be returned to the nearest Sunbeam Appointed Service Centre for adjustment or repair, if required.
- Do not operate any electrical appliance with a damaged cord or after the appliance has been dropped or physically damaged. If damage is suspected, return the appliance to the nearest Sunbeam Appointed Service Centre for examination, repair or adjustment.
- For additional protection the installation of a residual current device (RCD) with a rated current not exceeding 30mA is advisable in the electrical circuit supplying the power outlet in use.

If you have any concerns regarding the performance and use of your appliance, please ring our Toll Free number (Australia only) 1800 025 059. New Zealand - contact the Sunbeam Office in Auckland on 09 912 0747.

## Ensure the above safety precautions are understood.

تأكد من تفهم احتياطات السلامة المذكورة اعلاه

請務必理解上述的安全預防措施。

Assurez-vous que les précautions ci-dessus relatives à la sécurité sont bien comprises

Versichern Sie sich daß die obenstehenden Sicherheitsmaßnahmen Verstanden werden

Βεβαιώστε πως οι παραπάνω προφυλάξεις ασφαλείας γίνονται κατανοητές

Pastikan bahwa tindakan-tindakan keselamatan seperti di atas dimengerti anda

Accertatevi che le suddette norme di sicurezza siano comprese a dovere

上記の注意事項をよくお読みになり、安全を御確認ください

Уверете се дека погоре споменатите мерки на претпазливост се добро разбрани

Asegúrese de que las precauciones de seguridad precedentes sean bien comprendidas

کاری بکنید کہ احتیاط‌های بالا حتماً درک بشوند


ต้องแน่ใจว่า ข้อควรระวังเรื่องความปลอดภัยข้างต้น เป็นที่เข้าใจกันดี

Yukarda belirtilen güvenlik önlemlerinin anlaşıldığından emin olunuz

Xin kiểm chắc rằng những biện pháp làm an toàn kể trên được hiểu rõ

# Features of your Cordless Filter Kettle.

---



## **1.8 Litre Capacity.**

Handles large boiling requirements.

## **Fast boil 2400w element.**

Boils 2 cups in around 60 seconds.

## **Power Base.**

Cordless for greater convenience. The power base also features a cord storage cavity underneath for safe convenient storage of excess cord.

## **Hinged Lid.**

Makes the kettle easy to fill and clean.

## **Full-length Water Gauge.**

Indicates the amount of water in the kettle.

## **Removable Scale Filter.**

The long life stainless steel mesh filter traps scale for cleaner water, and is removable for easy cleaning.

## **Illuminated ON/OFF Boil Switch with Auto Cut-Out.**

Lights up to indicate that the kettle is on and heating. Automatically switches the kettle off after boiling.

## **3 Way Safety System.**

- 1 - Switches off after boiling.
- 2 - Cuts out for boil-dry protection.
- 3 - Shuts down in case of overheating.



# Using your Cordless Filter Kettle.

---

## **Before using your kettle.**

It is recommended that you clean your kettle before use by boiling a full kettle of water then discarding the water.

## **Using your kettle**

1. To fill the kettle, remove it from the power base and lift the lid. Fill with the desired amount of water. Alternatively, the kettle may be filled through the spout.

Always fill the kettle between the minimum and maximum marks. Too little water will result in the kettle switching off before the water has boiled. Too much water may cause it to spill out of the spout when boiling.

Ensure that the lid is firmly in place before placing the kettle on the power base.

2. Connect the 3 pin plug into a 230-240 volt AC power outlet. Turn the power ON.
3. Position the kettle on the power base. Press the ON/OFF button. The power indicator light will light up. The kettle will switch off automatically once the water has boiled.

**NOTE: Ensure that the ON/OFF switch is clear of obstructions and the lid is firmly closed. The kettle will not turn off if the switch is constrained or if the lid is left open.**

4. Lift the kettle from the power base and pour the water.

**NOTE: Use caution when pouring the water from your kettle, as boiling water will scald.**

5. The kettle may be stored on the power base when not in use. The kettle will not re-boil until the ON/OFF switch is pressed downward.

**NOTE: Ensure the power is turned OFF while the kettle is not in use.**

Should you accidentally allow the kettle to operate without water, the boil-dry protection will automatically switch it off. If this should occur, allow the kettle to cool before filling with cold water and re-boiling.

## **Cord Storage Facility**

Excess cord can be stored by feeding the cord into the storage cavity underneath the power base.

# Sunbeam's 3 Way Safety System.

---



Safety is a major consideration in the design of a Sunbeam kettle. That is why we have developed our 3 Way Safety System, which ensures that your kettle will:

## **1. Automatically switch off after boiling.**

For convenience, safety and energy efficiency, your Sunbeam kettle features an auto cut-out device.

## **2. Cut-out for boil-dry protection.**

If the kettle is operated without water, it will automatically cut-out, preventing any damage to the element.

## **3. Shut-down in case of overheating.**

In the event of overheating, the kettle will automatically shut down to prevent further damage. Should this occur, take your kettle to a Sunbeam Service Centre or Appointed Service Agent.

# Care and Cleaning.

---

Always remove the plug from the power outlet before cleaning.

Never immerse the kettle switch area or cord in water, or allow moisture to come into contact with these parts.

## **Removal of mineral deposits.**

Mineral deposits in tap water may cause the kettle interior to discolour. To remove this build-up, use Sunbeam Liquid Descaler, a simple to use, non-toxic cleaner available from Sunbeam Service Centres.

Alternatively:

1. Fill the kettle with 3 cups of white vinegar and the remainder with water and allow to stand overnight. **DO NOT BOIL.**
2. Empty the solution from the kettle. Any stains remaining inside the spout can be removed by rubbing with a damp cloth. Fill the kettle with clean water, bring to boil and then discard the water. Repeat and the kettle will then be ready to use.

The outside of the kettle can be wiped over with a damp cloth.

**CAUTION: Do not use chemical, steel wool, or abrasive cleaners to clean the outside of the kettle.**

*Sunbeam is a Registered trademark. Made in China. Due to minor changes in design or otherwise, the product you buy may differ from the one shown in this booklet. Approved by the appropriate Electrical Supply Authorities. Backed by Sunbeam's 12 Month Replacement Guarantee and National Service Network.*

© Copyright. SUNBEAM CORPORATION LIMITED 2001.  
(INCORPORATED IN N.S.W.) A.C.N. 000 006 771

*For more information or advice on any Sunbeam products, contact the Sunbeam Consumer Service Line on 1800 025 059 in Australia. In New Zealand - contact the Sunbeam Office in Auckland on 09 912 0747.*

---